


zmodo™

QUICK START GUIDE

SMART WIRELESS HOME CAMERA



Congratulations!

Thank you for purchasing our product, and welcome to a smarter world.

1

Quick setup guide

● Setting up your camera

Follow the instructions to set up your camera. To get started, all you need is a smartphone and WiFi:

- 1 Connect your Android™ phone or iPhone® to the WiFi network that you want your camera to use. Make sure that you know the password to connect to this network.

System Requirements: Android™ (v.4.0 or newer), or iPhone®, iPad®, iPod touch® (v.7.0 or newer), a password-protected 2.4GHz WiFi network.

- 2 Download and install the 'MeShare' app from Google Play™ or the App Store™. Launch the app and sign up for a free MeShare account.



MeShare



- 3 Log in and press the + Add Device option located on the bottom of the screen. Follow the on-screen instructions to complete your setup!

2

Recording & Live view

● Now compatible with MeShare!

We have partnered with MeShare to bring you optional cloud services! The MeShare Cloud Service (MCS) allows you to:

- Record continuously and store the footage on our secure cloud servers.
- Create and save video clips from your recordings.
- Access your playback footage and clips from any location with Internet connection.
- Share recorded footage and clips with family and friends.
- Access more smart features in the future!

Visit www.meshare.com/cloud for more information on plans and features.


● **MeShare Web App**

You can also view your device on any computer using MeShare's free web app. Simply use your MeShare user-name and password and log in to user.meshare.com.


3

Mounting your camera


- 1 Push the round mounting plate with your thumb to separate the mounting plate with the camera body. Keep the bracket attached to the camera.
- 2 Line the round mounting plate against the wall and mark the appropriate holes. Drill three holes slightly smaller than the wall anchor and use a hammer to gently insert the anchors into the wall. Fasten the three screws through the holes on the round mounting base and into the anchors.



- 3 Take the camera with the bracket (already attached together out of the factory) and attach it to the round mounting plate. You can rotate the whole bracket basing on the mounting base and adjust the camera to a direction with a better view.



- 4 Connect the supplied power adapter to the power input on the camera and then plug the power adapter into an electrical outlet. The LED indicator of the camera lights up when the camera is connected to a power source.



4

Troubleshooting



Solid green

The camera is powering on.



Blinking green

The camera is ready for SmartLink setup.



Solid blue

The camera has successfully connected to the WiFi network.



Blinking blue

The camera is connecting to the WiFi network. Please do NOT turn off or unplug the camera.



Solid red

The camera can't connect to the WiFi. Why?

You may have entered the password incorrectly. Try re-entering your WiFi password.

You may not have a working internal connection. Check to see if your router is connected to the Internet. Try resetting your camera by pressing the reset pinhole on the back of the camera. Hold the button until the light turns blinking green. Then begin the setup procedure again.



Having difficulty? For more instructions, troubleshooting, support information, our knowledge base, the community forum, and other resources, please visit:

<http://www.zmodo.com/supports>

5

Connect with us!



Like us on [Facebook.com/Zmodo](https://www.facebook.com/Zmodo)
Scan the QR-code below!



Follow us on Twitter @Zmodo
Scan the QR-code below!



Android is a trademark of Google Inc. Google Play is a trademark of Google Inc. Apple, the Apple logo, and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.